1861439 K-X-Pi MOD Sofa Unit-Blue Microfiber
1861442 K-X-Pi MOD Sofa Unit-Chocolate Microfiber

Parts List

A.	Seat Assembly	1 pc
B.	Front Legs	2 pcs
C.	Sofa Back	1 pc
D.	Crest Cushion	1 pc
E.	Allen Head Bolts	4 pcs
F.	Allen Head Wrench	1 pc

∗ Please make sure that you have all the parts indicated above before you begin assembly of this item.
∗ This item should be assembled on a soft surface to prevent scratching the finish during assembly.
∗ This item may require periodic tightening**.**
∗ This item is to be assembled by an adult and is not intended to be taken apart by a child.

Assembly Instructions

1. **Attach Front Legs (B)** Put the Seat Assembly (A) upside down on a soft surface. Align the exposed threads of Front Legs (B) with the pre-threaded holes in the front corner of Seat Assembly (A). Tighten by turning in a clockwise direction. See Illustration.
2. **Attach Sofa Back (C)** Place the Seat Assembly (A) face down on a soft surface. Pull the fabric flaps on the back open. Align the pre-drilled holes in tube of Sofa Back (C) with the pre-threaded holes in the Seat Assembly (A). Secure with Allen Head Bolts (E) using Allen Head Wrench (F). Replace the fabric flaps over the tubes. See Illustration.
3. **Attach Crest Cushion (D)** Pull the fabric flap of Crest Cushion (D) open. Insert the top rail of Sofa Back (C) into Crest Cushion (D). Replace the fabric flap over tube. See Illustration.

Note: Fabric of Seat Assembly (A) and Crest cushion (D) can be removed for washing.